Installation Manual



Components list











Pre-installation

TOOLS REQUIRED



HARDWARE INCLUDED



Section drawing



Installation





Installation

3

A



Ø10 (x3)

(x3)

M8x90 (x3)

G

(x3)



4

E

(x3)

ST3.5x30 (x12)







Installation

5

H



(x2)

ST4.8x50 (x4)





6

B



(x1)

C



(x1)



Installation

7

F



(x1)



Ø8 (x4)

ST4.2x32 (x4)









Installation

8



Installation

9



Installation

10

D



(x1)

(x1)

(x1)